

Carefree of Colorado

ONE-Touch Strap Guide instructions

NOTE: COVER AND STRAP ARE NOT SHOWN FOR ILLUSTRATION PURPOSES .

1. Disconnect Rafter from bracket, push Rafter forward, depress Rafter Spring, and pull Rafter back off the Roll Pin and out of way (see figure A).
2. Insert Strap Guide into arm under strap and between the 1/4" inserts as shown in figure B & C. Note: No fasteners are needed to hold Strap Guide in place.
3. Route Strap through Strap Guide as shown in figure D.
4. Reconnect Rafter on Roll Pin of bracket as shown in figure A.

